

MACHINE TYPE - VC4 / 5 / 7

Part Number	Alternative Number	Description	Std	Mod
446 O4 OO1		Chuck Proper	X	
446 O4 OO2		Slide	X	
446 O4 OO5		Pawl	X	
446 O4 OO6		Stopper	X	
446 O4 OO8		Holder	X	
446 O4 OO9		Spring Holder	X	
446 O4 O10		Holder Cap	X	
446 O4 O11		Spring Hook	X	
446 O4 O12		Pin 'A'	X	
446 O4 O13		Pin 'B'	X	
446 O4 O14		Pin 'C'	X	
446 O4 O15		Roller	X	
446 O4 O3L		Pawl - 'L/Hand'	X	
446 O4 O3R		Pawl - 'R/Hand'	X	
446 O4 17A		Compression Spring	X	
446 O5 OO2		Tape Clamp	X	
446 O6 OO8		Upper Blade	X	
446 O7 OO4		Roller	X	
446 O7 O10		Cylinder Holder	X	
446 O7 O12		Pin	X	
446 O8 OO2		Bush	X	
446 O8 OO4		Plate	X	
446 O8 OO6		Collar	X	
446 O8 OO7		Joint	X	
446 O8 OO9		Washer	X	
446 O8 O10		Pin	X	
446 O8 O11		Link Lever	X	
446 O8 O14		Bush	X	
446 O8 O15		Shaft	X	
446 O8 O2B		Bush	X	
446 O8 O5L		Pivot Pin	X	
446 O8 O5R		Pivot Pin	X	
446 O8 13A		Lever	X	
446 O8 13B		Lever	X	
446 O8 16D		Cutter	X	
446 O8 16U		Cutter	X	

446 09 002		Bracket	X	
446 09 003		Arm	X	
446 09 004		Pin	X	
446 09 005		Stopper	X	
446 09 007		Pin	X	
446 09 008		Cylinder Piston	X	
446 09 009		Cylinder	X	
446 09 010		Lid	X	
446 09 011		Joint	X	
446 09 012		Link	X	
446 09 015		Shaft	X	
446 09 016		Joint	X	
446 09 017		Collar	X	
446 09 018		Gear	X	
446 09 019		Rack - Double Sided	X	
446 09 020		Cylinder	X	
446 09 021		Lid	X	
446 09 022		Stopper	X	
446 09 024		Cylinder	X	
446 09 025		Key	X	
446 09 026		Cylinder Support	X	
446 09 027		Cylinder Stopper	X	
446 09 028		Bush	X	
446 09 029		Piston	X	
446 09 030		Nut	X	
446 09 031		Stopper	X	
446 09 033		Cam Mounting	X	
446 09 06A		Cushion Rubber	X	
446 09 06B		Cushion Rubber	X	
446 09 06D		Cushion Rubber	X	
446 09 06E		Cushion Rubber	X	
446 09 13A		Joint Pin	X	
446 09 13B		Bracket	X	
446 09 150		Clinch Shaft	X	
446 09 151		Collar	X	
446 10 006		Collar	X	
446 10 018		Key	X	
446 10 019		Gear	X	
446 10 021		Nut	X	
446 10 022		Rack	X	
446 10 023		Luck Guide	X	

446 10 O24		Hook	X	
446 10 O25		Spring Hook	X	
446 10 O27		Connecting Rod	X	
446 10 O30		Push Rod Arm	X	
446 10 O31		Washer	X	
446 10 O34		Slide For Push Rod	X	
446 10 O35		Pivot Pin	X	
446 10 O37		Bearing Pin	X	
446 10 O38		Pin Holder	X	
446 10 O39		Washer	X	
446 10 O40		Pin	X	
446 10 O42		Push Rod Washer	X	
446 10 O45		Shaft	X	
446 10 O46		Washer	X	
446 10 O48		Lever	X	
446 10 O52		Spacer	X	
446 10 O54		Roller Pin	X	
446 10 O57		Rod End Pin	X	
446 10 O59		Rod End Pin	X	
446 10 O61		Chuck Open Key	X	
446 10 O65		Pin	X	
446 10 O67		Pin	X	
446 10 O68		Cylinder Bracket	X	
446 10 O70		Cylinder Joint	X	
446 10 O71		Pin	X	
446 10 117		Shaft	X	
446 10 120		Compression Spring	X	
446 10 123		Spring	X	
446 10 132		Spring	X	
446 10 134		Tension Spring	X	
446 10 143		Hook	X	
446 10 145		Spring	X	
446 10 148		Bolt	X	
446 10 149		Cushion Rubber	X	
446 10 155		Nut	X	
446 10 158		Compression Spring	X	
446 10 174		Cushion Rubber	X	
446 10 180		Clamp Shaft	X	
446 10 43D		Washer	X	
446 10 43U		Washer	X	
446 10 48B		Lever	X	

446 1O 72B		Pin	X	
446 1E 05L		Link - L/Hand	X	
446 1E 05R		Link - R/Hand	X	
446 1E 17A		Spring	X	
446 1E 17B		Spring	X	
446 1E 17C		Spring	X	
446 1E 20L		Slide Bush	X	
446 1E 20R		Slide Bush	X	
446 1E 301		Main Guide	X	
446 1E 302		Sub Guide - R/Hand	X	
446 1E 303		Sub Guide - L/Hand	X	
446 1E 304		Guide Holder	X	
446 1E 306		Link	X	
446 1E 307		Link Pin	X	
446 1E 308		Link Pin	X	
446 1E 309	556 B 2070	Cushion Pin	X	
446 1E 310		Cushion Spring	X	
446 1E 312		Joint Piece	X	
446 1E 313		Pin	X	
446 1E 314		Link Holder	X	
446 1E 315		Link Holder	X	
446 1E 316		Spring Hook	X	
446 1E 318		Spring	X	
446 1E 31R		Push Rod	X	
446 1E 342		Stopper Screw	X	
446 1G 121		Chuck	X	
446 1G 122		Pawl	X	
446 1G 123		Pawl	X	
446 1G 212		Lead Holder	X	
446 1G 222		Spring	X	
446 1Q O26A	446 1O O36	Brass Brake	X	
446 9T OO1		Cutter Proper	X	
446 9T OO2		Cutter Cover	X	
446 9T OO3		Bending Cutter	X	
446 9T OO4		Bending Cutter	X	
446 9T OO5		Block	X	
446 9T OO6		Joint	X	
446 9T OO7		Bracket	X	
446 9T OO8		Bracket	X	
446 9T OO9		Pin - 'C'	X	
446 9T O10		Link - 'A'	X	

446 9T O11		Link - 'B'	X	
446 9T O12		Hexagon Head Bolt	X	
446 9T O13		Pin	X	
446 9T O14		Pin - 'A'	X	
446 9T O15		Pin - 'B'	X	
446 9T O16		Pin - 'D'	X	
446 9T O17		Detection Bracket	X	
446 9T O18		Bush	X	
446 9T O19		Spacer	X	
446 9T O21		Cutter Cover	X	
446 9T O23		Chute	X	
446 B O53A		Push Rod	X	
462 1Q OO5		Slider	X	
462 1Q O13		Bracket	X	
462 1Q O14		Pin	X	
462 1Q O15		Pin	X	
462 1Q O16		Washer	X	
462 1Q O17		Pin	X	
462 1Q O19		Push Rod Arm	X	
462 1Q O20		Pin	X	
462 1Q O21		Slide Block	X	
462 1Q O22		Guide Mounting Plate	X	
462 1Q O23		Guide Mounting Plate	X	
462 1Q O24		Slider	X	
462 1Q O25		Pin	X	
462 1Q O26		Clamp	X	
462 1Q O27		Spring Hook	X	
462 1Q O28		Pin Holder	X	
462 1Q O29		Pin	X	
462 1Q O30		Slider Block	X	
462 1Q O31		Washer	X	
462 1Q O32		Hook	X	
462 1Q O37		Washer	X	
462 1Q O38		Clamp Lever	X	
462 1Q O39		Pin	X	
462 1Q O42		Push Rod Lever	X	
462 1Q O43		Pin	X	
462 1Q O55		Guide Up/Down Lever	X	
462 1Q O56		Chuck Open Lever	X	
462 1Q O57		Washer	X	
462 1Q O58		Pin	X	

462 1Q 063		Guide Closed Lever	X	
462 1Q 065		Thrust Washer	X	
462 1Q 066		Pin	X	
462 1Q 067		Collar	X	
462 1Q 069		Lever	X	
462 1Q 070		Thrust Washer	X	
462 1Q 071		Thrust Washer	X	
462 1Q 072		Pivot Pin	X	
462 1Q 073		Bush	X	
462 1Q 074		Slider Shaft	X	
462 1Q 075		Slider Shaft	X	
462 1Q 076		Bracket	X	
462 1Q 077		Joint Pin	X	
462 1Q 078		Link	X	
462 1Q 079		Pin Holder	X	
462 1Q 208		Cam Shaft	X	
512 A 1130		Arm Roller	X	
512 A 1150		Locating Arm	X	
512 B 0080		Pulley Pin	X	
512 B 0320		Connecting Rod	X	
512 B 0700		Roller	X	
512 B 0990		Stopper	X	
552 02 038		Pulley Pin	X	
556 01 023/024		PCB Guide Rails with Cover	X	
556 02 504		Center Shaft Gear	X	
556 30 214		Plate	X	
556 30 226		Position Guide	X	
556 05 006		Spring	X	
556 05 007		Pivot Pin	X	
556 05 008		Slider Block	X	
556 05 033		Turn Buckle	X	
556 05 047		Stud	X	
556 05 172		Arm	X	
556 05 173		Arm	X	
556 05 174		Pawl	X	
556 05 175		Pawl	X	
556 05 187		Plate	X	
556 05 191		Shaft	X	
556 05 192		Pin	X	
556 05 193		Roller	X	
556 05 251		Compression Spring	X	

556 06 294		Spring	X	
556 06 519		Cam Shaft Gear	X	
556 07 002		Pallet Guide	X	
556 07 004		Slider Retainer	X	
556 07 005		Slider	X	
556 07 006		Swing Arm	X	
556 07 007		Pivot Pin	X	
556 07 010		Pivot Pin	X	
556 07 012		Tension Spring	X	
556 07 021		Stopper Pin	X	
556 07 022		Spring	X	
556 07 026		Feed Wheel	X	
556 07 033		Cutter Pivot Pin	X	
556 07 034		Tape Guide	X	
556 07 042		Sensor Spring	X	
556 07 044		Tape Guide	X	
556 07 047		Pin	X	
556 07 048		Spring	X	
556 07 062		Ratchet Spring	X	
556 07 063		Pin	X	
556 07 067		Cutter Base	X	
556 07 068		Tape Cutter	X	
556 07 151		Base	X	
556 07 152		Swing Arm	X	
556 07 153		Tape Clamp	X	
556 07 154		Tape Clamp	X	
556 07 155		Swing Arm	X	
556 07 205		Spring	X	
556 07 805		Pallet Unit	X	
556 07 810		Swing Arm Assembly	X	
556 08 007		Chuck Lever	X	
556 08 008		Pin	X	
556 08 013		Lever	X	
556 10 007		Connecting Rod	X	
556 10 008		Connecting Rod	X	
556 10 010		Lever	X	
556 10 011		Washer	X	
556 10 012		Pin	X	
556 10 030		Cushion Rubber	X	
556 10 031		Washer	X	
556 10 076		Stand	X	

556 1O 150		Rack	X	
556 1E 001		Main Guide	X	
556 1E 002		Sub Guide - L/Hand	X	
556 1E 003		Sub Guide - R/Hand	X	
556 1E 502		Link	X	
556 1E 510		Lever	X	
556 1E 511		Joint Piece	X	
556 1E 512		Joint Pin	X	
556 1E 513		Rod End Pin	X	
556 3O 209		Holder Plate	X	
556 3O 213		Pin	X	
556 3O 214		Plate	X	
556 3O 220		Pin	X	
556 3O 222		Bolt	X	
556 3O 223		Hook	X	
556 3O 225		Cam	X	
556 3O 226		Guide	X	
556 A 0010		Frame Unit	X	
556 A 0020		Bracket	X	
556 A 0030		Hinge Pin 'A'	X	
556 A 0040		Arm Up	X	
556 A 0050		Arm Down	X	
556 A 0060		Pawl	X	
556 A 0070		Link Plate	X	
556 A 0080		Pin - 'A'	X	
556 A 0090		Shaft - 'A'	X	
556 A 0100		Pin - 'B'	X	
556 A 0111		Pawl Up	X	
556 A 0121		Pawl Down	X	
556 A 0131		Holder Up	X	
556 A 0132		Holder Down	X	
556 A 0140		Link Arm - 'A'	X	
556 A 0150		Link Arm - 'B'	X	
556 A 0160		Link Plate	X	
556 A 0170		Pin - 'B'	X	
556 A 0180		Hinge Pin	X	
556 A 0190		Shaft - 'B'	X	
556 A 0200		2 Knuckle Joint	X	
556 A 0210		Slider Bush	X	
556 A 0220		Shaft Lever	X	
556 A 0230		Pin - 'C'	X	

556 A 0240		2 Knuckle Joint	X	
556 A 0270		Knuckle Joint	X	
556 A 0280		Cylinder Bracket	X	
556 A 0400		Positioning Bracket	X	
556 A 1130		Arm Holder	X	
556 A 1150		Arm	X	
556 B 0301		Guide Block	X	
556 B 0420		Push Rod Assembly	X	
556 B 0440		Push Rod Piece	X	
556 B 044A		Push Rod Piece	X	
556 B 0450		Link - R/Hand	X	
556 B 0451		Link - R/Hand	X	
556 B 0460		Link - L/Hand	X	
556 B 0461		Link - L/Hand	X	
556 B 0480		Bush	X	
556 B 0910		Push Rod	X	
556 B 1330		Rack Guide	X	
556 B 1340		Piston Rod	X	
556 B 1370		Spring	X	
556 B 1410		Clamp Shaft	X	
556 B 1420		Washer	X	
556 B 1421		Washer	X	
556 B 1450		Cylinder Bracket	X	
556 B 1470		Bolt	X	
556 B 1490		Clamp Piece	X	
556 B 2060		Push Rod	X	
556 B 206A		Push Rod	X	
556 B 2070		Cushion Pin	X	
556 B 2080		Pin	X	
556 B 2100		Slider	X	
556 B 2110		Slider	X	
556 B 2120		Clamp Shaft	X	
556 B 2121		Clamp Shaft	X	
556 B 212A		Clamp Shaft	X	
556 B 2130		Cap	X	
556 B 2131		Cap	X	
556 B 2140		Washer	X	
556 B 2150		Washer	X	
556 B 2160		Push Rod	X	
556 B 2170		Tension Spring	X	
556 B 2180		Clamp	X	

556 B 2190		Clamp Piece	X	
556 B 2200		Pivot Pin	X	
556 B 2210		Pin	X	
556 B 2230		Tension Spring	X	
556 B 2240		Compression Spring	X	
556 B 2250		Tension Spring	X	
556 B 2260		Spring Hook	X	
556 B 2290		Pin	X	
556 B 2320		Chuck Open Key	X	
556 B 2350		Clamp	X	
556 B 2360		Clamp Piece	X	
556 B 2361		Clamp Piece	X	
556 B 2370		Pin	X	
556 B 2380		Compression Spring	X	
556 B 2390		Compression Spring	X	
556 B 2400		Washer	X	
556 B 2410		Guide Holder	X	
556 B 6020		Cushion Spring	X	
556 B 6110		Cushion Pin	X	
556 E 0300		Guide Block	X	
556 E 0301		Guide Block	X	
556 E 0311		Main Guide	X	
556 E 0320		Sub Guide - R/Hand	X	
556 E 0330		Sub Guide - L/Hand	X	
556 E 0360		Sub Guide - R/Hand	X	
556 E 0370		Sub Guide - L/Hand	X	
556 E 0610		Main Guide	X	
556 E 0620		Sub Guide - R/Hand	X	
556 E 0630		Sub Guide - L/Hand	X	
556 E 1610		Main Guide	X	
556 E 1620		Sub Guide - R/Hand	X	
556 E 1660		Sub Guide - R/Hand	X	
556 E 1670		Sub Guide - L/Hand	X	
556 E 1810		Main Guide	X	
556 E 1820		Sub Guide - R/Hand	X	
556 E 1830		Sub Guide - L/Hand	X	
556 E 1860		Sub Guide - 'R/Hand'	X	
556 E 1870		Sub Guide - 'L/Hand'	X	
556 G 0311		Main Guide	X	
556 G 1610		Main Guide	X	
556 G 1620		Sub Guide - 'R/Hand'	X	

556 G 1640		Sub Guide	X	
556 G 1680		Main Guide	X	
556 G 1690		Sub Guide - 'L/Hand'	X	
556 G 1810		Main Guide	X	
556 G 1890		Sub Guide - 'L/Hand'	X	
556 L 0010		Chuck Body	X	
556 L 0020		Pawl	X	
556 L 0030		Pawl	X	
556 L 0040		Chuck Pin	X	
556 L 0110		Chuck Body	X	
556 L 0120		Chuck Block	X	
556 L 0130		Pawl	X	
556 L 0140		Pawl	X	
556 N 0032		Bending Cutter	X	
556 N 0033		Bending Cutter - '1A'	X	
556 N 0042		Bending Cutter	X	
556 N 0043		Bending Cutter - '2A'	X	
556 N 0093		Detection Block Cover	X	
556 N 0094		Detection Block Cover	X	
556 N 0110		Detection Block	X	
556 N 0120		Detection Block	X	
556 N 1012		Cutter Proper	X	
556 N 1026		Cutter Lid	X	
556 N 1028		Cutter Lid	X	
556 N 1032		Bending Cutter - '1A'	X	
556 N 1033		Bending Cutter	X	
556 N 1035		Bending Cutter - '1A'	X	
556 N 1042		Bending Cutter - '2A'	X	
556 N 1043		Bending Cutter	X	
556 N 1045		Bending Cutter - '2A'	X	
556 N 2010		Cutter Proper	X	
556 N 2020		Cutter Lid	X	
556 N 2030		Bending Cutter	X	
556 N 2040		Bending Cutter	X	
556 N 2050		Pin - 'A'	X	
556 T 0012		Cutter Proper	X	
556 T 0020		Cutter Cover	X	
556 T 0032		Bending Cutter - 'Side'	X	
556 T 0042		Bending Cutter - 'Center'	X	
556 T 0060		Pin	X	
556 T 0070		Link - 'A'	X	

556 T 0080		Link - 'B'	X	
556 T 0090		Spacer	X	
556 T 0100		Spacer	X	
556 T 0130		Cutter Proper	X	
556 T 0140		Cutter Lid	X	
556 T 0150		Bending Cutter - 'Side'	X	
556 U 0100		Detection Block	X	
556 U 1000		Block	X	
556 U 1010		Joint	X	
556 U 1020		Bracket - 'A'	X	
556 U 1030		Bracket - 'B'	X	
556 U 1040		Hexagon Head Bolt	X	
556 U 1050		Pin - 'A'	X	
556 U 1060		Pin	X	
556 U 1070		Pin	X	
556 U 1080		Pin - 'D'	X	
556 U 1090		Dust Chute	X	
556 U 1092		Dust Chute	X	
556 W 5081		Hexagon Head Bolt	X	
556 W 6041		Link - 'A'	X	
556 W 7051		Pin - 'A'	X	
561 F 0721		Spring	X	
561 F 0730		Slider	X	
561 F 0740		Shaft	X	
561 F 0750		Spring Hook	X	
561 G 4130		Pin	X	
561 H 4261		Joint Piece	X	
561 J 0172		Rod	X	
561 J 0410		Gear	X	
561 J 0640		Rubber Shaft	X	
561 J 0770		Bolt	X	
561 J 0780		Bolt	X	
561 P 3040		Pivot Pin	X	
561 R 0010		Pin	X	
561 R 0020		Link Lever	X	
561 R 0030		Washer	X	
561 R 0040		Pin	X	
561 R 0080		Lever	X	
561 R 0090		Lever	X	
561 R 0100		Lever	X	
562 F 0910		Spring	X	

562 F 0990		Lead Holder	X	
562 F 1000		Bolt	X	
562 F 1011		Lead Guide	X	
562 F 1043		Compression Spring	X	
562 F 1120		Spring	X	
562 F 1430		Cam	X	
562 G 0010		Spring Pawl	X	
562 G 0030		Holder	X	
562 G 0060		Chuck Proper	X	
562 G 0070		Pawl	X	
562 G 0080		Pawl	X	
556 G 0102		Compression Spring	X	
562 H 0041		Pin Retainer	X	
562 H 0070		Roller	X	
562 H 0080		Shaft	X	
562 H 0102		Slider	X	
562 H 0150		Joint Pin	X	
562 H 0170		Pin Holder	X	
562 H 0200		Clamp Shaft	X	
562 H 0320		Tension Spring	X	
562 H 0351		Push Rod	X	
562 H 0370		Spring	X	
562 H 1370		Push Rod Piece	X	
562 H 1400		Clamp Shaft	X	
562 J 0171		Plate	X	
562 K 0040		Cylinder	X	
562 K 0050		Key	X	
562 K 0080		Piston	X	
562 K 0090		Nut	X	
562 K 0100		Cushion	X	
562 K 0130		Gear	X	
562 K 1010		Cylinder Stopper	X	
562 K 1020		Piston	X	
562 K 1040		Nut	X	
562 K 1050		Joint	X	
562 P 0130		Compression Spring	X	
600 34 106		Bearing	X	
600 34 181		Bearing	X	
600 35 168		Cam Follower	X	
600 35 723		Lock Washer	X	